


## Dual Pod License Plate Mount

LPBM-03



### TOOLS REQUIRED

- Screwdriver

### SKILL LEVEL

- Novice/Intermediate  
- 1 Person

Little skill level required, you can easily install it by yourself however, additional help will be useful.

### TIME REQUIRED

- .5 Hours

Time to install this should take approximately .5 Hour.

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*


1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



# INSTALLATION MANUAL

## STEP 1


Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from.



## STEP 2

Begin by installing pod lights onto bracket using hardware provided with the lights.

*NOTE: We are using two 3" Inch elite series pods lights.*



## STEP 3

Once desired lights are installed on the bracket, remove the factory screws securing license plate to the vehicle.



# INSTALLATION MANUAL

## STEP 4

Install the bracket assembly and plate to the vehicle using the factory screws. Secure with a screwdriver.

*Note: Be sure to keep wires from being pinched between the bracket and the body of the vehicle.*



## STEP 5

Run wires into vehicle and wire lights as desired.

*NOTE: Wire management and light wiring will vary with vehicle.*



# INSTALLATION MANUAL

---

## STEP 6

Double check all hardware is secure and if running optional pods, wire lights as desired.

