



**DOWNLOAD THE LATEST INSTALL
MANUALS AT www.bddiesel.com**



FRONT DIFFERENTIAL COVER KIT

2003-2013 2500 Dodge AA14-9.25

2003-2012 3500 Dodge AA14-9.25

Part #: 1061826

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLATION

KIT CONTENTS:

Please check to make sure that you have all the parts listed in this kit **before** you start the disassembly of your truck.

1601826




Differential cover

QTY: 1		Qty: 1	
1601715	1601512	1601613	1401557
			
Bolt M8-1.25 X 30mm	Washer 5/16"	Drain Plug 3/4-16	Plug -10 ORB
Qty: 14	Qty: 14	Qty: 1	QTY: 1

Removal




Ensure the vehicle is secure on a hoist or using wheel chocks to prevent rolling and apply the parking brake. Do not install this cover on ground that is not level. Ensure differential fluid is cool before starting this removal/ installation procedure. Removal of the spare tire may provide better access.



1. Place a drain pan under the differential.
2. Remove all bolts starting at the bottom. Do not remove the **top bolt**.
3. Loosen the top bolt half way, this will prevent the cover from falling once you pry the cover from the housing. Do not damage the re-suable gasket, you will need to re-use it.
4. Once the cover is free remove top bolt / cover and clean the gasket surface.

Installation



1. Install the drain plug into the BD diff cover (8mm Allen wrench). Do not overtighten.
2. Check differential housing gasket surface for irregularities and remove high spots if required. Surface must be flat and clean.
3. Apply a thin layer of oil to the OE reusable gasket then install between diff and BD cover.
4. Using the supplied bolts and washers fasten the BD diff cover to the housing and tighten finger tight starting from the top (6mm Allen Wrench).
5. Once all bolts are finger tight you can torque to 24-30 ft/lbs in a crisscross pattern.
6. Fill differential with manufacturer specified gear oil/ amount 2.5 Quarts for the BD differential cover following manufactures filling procedures.
7. Insert fill plug (1401557) do not overtighten (9mm Allen wrench).

Some differentials may require special additives, please check your owner's manual before filling. Drive at least 50 kms (31 miles) then re-torque bolts to specification and ensure there are no leaks. Installation is complete.

Thank you for purchasing BD product If you have any technical difficulties, concerns, comments, or complaints, please phone our Technical Support hotline at(800) 887-5030 between 8:30am-5:00pm PST (Pacific Standard Time) Monday to Friday.