



Sway Bar Installation Instructions

Tools Required:

- Hydraulic jack and jack stands
- ½" and 9/16" wrench and socket

Instructions:

1. Raise the front of the car in the air and secure with jack stands.
2. Remove the front sway bar end links.
3. Remove the four (4) bolts holding the rear sway bar saddles on the frame with a ½" socket.
4. Grease the sway bar bushings using synthetic grease (**SUL41150**) and place them on the outside of the washers on the sway bar. Next press the saddles over the bushings.
5. Mount the sway bar saddles to the frame and the end links to the control arm. **Do not tighten.**
6. With the bar loose in the saddles, center the bar and ensure that there is clearance for the control arms and the steering linkages.
7. Tighten the sway bar saddle bolts to **80 ft-lbs**
8. Tighten the end links until the bushings compress.
9. Reinstall wheels and lower vehicle.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicle's manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.