

# BOLT®

BREAKTHROUGH ONE-KEY LOCK TECHNOLOGY

# J-MOUNT

FOR SPANISH AND FRENCH TRANSLATIONS GO TO:  
[HTTP://WWW.BOLTLOCK.COM/ABOUT-STRATTEC/BOLT-LITERATURE](http://www.boltlock.com/about-strattec/bolt-literature)

LOS TRADUCTORES AL ESPAÑOL Y FRANCÉS PUEDEN VISITAR:  
[HTTP://WWW.BOLTLOCK.COM/ABOUT-STRATTEC/BOLT-LITERATURE](http://www.boltlock.com/about-strattec/bolt-literature)

POUR LES TRADUCTIONS EN ESPAGNOL ET EN FRANÇAIS, ALLEZ À :  
[HTTP://WWW.BOLTLOCK.COM/ABOUT-STRATTEC/BOLT-LITERATURE](http://www.boltlock.com/about-strattec/bolt-literature)



J-MOUNT BRACKET



2X 5/16" X 1 1/4"  
BOLTS



2X FLAT WASHERS



2X LOCK WASHERS



RUBBER GASKET




2X KNOBS




BOLT RECEIVER HEAD


## INSTRUCTIONS FOR CODING LOCK CYLINDER



READ AND REMOVE WARNING STICKER - REMOVE KEY FROM KEY CHAIN



*DO NOT PULL UP/DOWN ON KEY WHILE CODING*  
WHILE MAINTAINING FULL KEY INSERTION, TURN THE KEY  
CLOCKWISE UNTIL IT STOPS




THE LOCK IS NOW SUCCESSFULLY CODED - CYCLE LOCK  
3X TO ENSURE THAT THE LOCK WAS PROPERLY CODED



# DO NOT INSTALL THE J-MOUNT BEFORE THE LOCK IS CODED TO YOUR KEY


## INSTRUCTIONS FOR INSTALLATION



REMOVE THE TWO LOWER TORX HEAD SCREWS FROM THE JEEP WINDSHIELD HINGE  
NOTE: YOU MAY NEED TO USE AN IMPACT WRENCH AND LOOSENING SOLVENT TO REMOVE THE SCREWS



PUT THE PLASTIC GASKET BETWEEN YOUR VEHICLE WINDSHIELD HINGE AND THE J-MOUNT BRACKET



SECURE THE J-MOUNT BRACKET TO THE WINDSHIELD HINGE WITH THE INCLUDED BOLTS, WASHERS AND LOCK WASHERS UNTIL FULLY TIGHTENED



PLACE YOUR HI-LIFT STYLE JACK IN POSITION AND SAFELY SECURE USING THE 2 PLASTIC KNOBS



ADJUST THE LOWER BUMPER IN ORDER TO KEEP THE JACK TIGHT AGAINST YOUR JEEP AND TO AVOID ANY RATTLING



ATTACH THE ENCLOSED BOLT LOCK TO YOUR J-MOUNT BRACKET TO LOCK YOUR HI-LIFT STYLE JACK IN PLACE

NOTE: IMAGES SHOW INSTALLATION ON THE DRIVER SIDE OF THE VEHICLE. FOR INSTALLATION OF A PASSENGER SIDE J-MOUNT PLEASE FOLLOW THE SAME STEPS BUT INSTALL THE J-MOUNT ON THE PASSENGER SIDE OF YOUR JEEP.