

PRP

Jeep Cherokee 1995-2001 (XJ) Mounting Instructions

1. Using a 1/2" wrench, remove your stock seats from the stock sliders (four flanged nuts)



2. Once both seats are removed, place the PRP seat adaptors onto the factory studs with the angle pointing up. (note: the wider adaptor plate should be on the inside toward the tunnel) Insert the factory nuts loosely to allow adjustment of the seat.



3. Install your new PRP seats using four 3/8 bolts and lock nuts. The seat tabs should rest on the outside of both angle brackets.



4. Lastly, tighten the four factory nuts to secure the adaptor plates in place

www.PRPSseats.com

800.317.6253

FAX 951.894.5108

43352 Business Park Dr, Ca 92592