



**BX1607 Installation Instructions
1985-90 Chevrolet/Geo Spectrum
1985-88 Isuzu I-Mark**

1. Read the General Instruction Sheet included with this baseplate.
2. The baseplate mounts to the front underside of the car using seven bolts, six existing and one which is supplied; three on each side and one in the center of the vehicle.
3. Remove the tie down bracket from each side of the vehicle and inspect the bolts for reuse. [See General Instruction Sheet]. The tie down bracket is a stamped metal bracket with an oblong hole facing downward.
4. Remove the bolt from the passenger's side only of the engine support brace. This bolt will be replaced with the longer bolt and lock washer which is provided.
5. Slide the baseplate under the front of the vehicle and note that the side three bolt pattern aligns with the tie down bracket holes. The center brace hole aligns with a bolts hold the engine support brace to the frame.
6. When all the bolts align, apply Loctite and tighten securely.
7. The dimensional variations between otherwise identical cars can be considerable. While the location and size of the holes in the baseplate were designed to allow easy installation, it may be necessary to file a hole slightly to allow a bolt to clear.
8. Install the tow bar and safety cables according to the instructions included in their packages.
9. Do not substitute other devices if the tow bar pin and clip are lost.
10. **DEALERS AND INSTALLERS:** BE CERTAIN THE USER RECEIVES THE INSTRUCTION SHEET.

Tools Required

3/4 socket

14mm socket

17mm socket

Automatic

Parts List

Ref. No.	Qty.	Part No.	Description
1	1	61-3357	Main Baseplate Assembly
2	1	201-0426	10mm-1.25 x 100mm Hex Bolt
3	1	203-0104	10mm Lock Washer

