



BX1812 Installation Instructions 1986 1/2-95 Nissan Pick-up (2WD)

Installation of this baseplate requires drilling 9/16" holes in the vehicle's tie down brackets.

1. Read the General Instruction Sheet included with this baseplate.
2. The baseplate mounts to the front underside of the car using six provided bolts, three on each side of the car.
3. In the bottom front of both frame rails, there is a hole which will be used to mount the baseplate. Check to see that the threaded end of a 1/2" bolt will pass through the hole and if necessary, enlarge the hole.
4. Above the holes just mentioned and on the outside of the frame rails is an oblong slot which will allow access to the bolt ends when installed.
5. Center punch the location of two 9/16" diameter holes to be drilled in each tie down bracket using the drawings provided as a template.
6. Pilot drill first, then drill to 9/16" diameter.
7. Position the baseplate and hand start the four 1/2" bolts, lockwashers, and nuts to attach the baseplate to the tie down brackets. Use locktite on all bolts but do not tighten yet.
8. Insert a 1/2" bolt with a lock washer through the baseplate and frame bottom hole. Insert a 1/2" nut with a tab welded to it into the slot on the frame side such that the tab goes in first and is on the bottom of the nut. Rotate the bolt to start the nut onto it.
9. When all bolts align, tighten securely.
10. The dimensional variations between otherwise identical cars can be considerable. While the location and size of the holes in the baseplate were designed to facilitate easy installation, it may be necessary to file a hole slightly to allow a bolt to clear.
11. Install the tow bar and safety cables according to the instructions included in their packages.
12. Do not substitute other devices if the pin and clip are lost.
13. DEALER OR INSTALLER: BE CERTAIN THE USER RECEIVES THE INSTRUCTION SHEET.

Tools Required

3/4" socket
Hammer

3/4" open-end wrench
9/16" Drill

Center Punch

Parts List

| Ref. No. | Qty. | Part No. | Description |
|----------|------|----------|---|
| 1 | 1 | 61-3360 | Baseplate, BX1812 |
| 2 | 2 | 61-3359 | Hex Nuts with tabs |
| 3 | 6 | 201-0051 | 1/2-13 x 1 1/2 Hex Head Bolt |
| 4 | 4 | 202-0005 | 1/2-13 Hex Nut |
| 5 | 6 | 203-0012 | 1/2 Lock Washer |
| | 2 | 226-0049 | Baseplate Safety Cable, 36" CL IV (Not Shown) |
| | 4 | 229-0512 | Quicklink, 1/2, ZP (Not Shown) |

Automatic

