

# **BORGESON**

***Steering You Forward***

## #800334 Ford 200/250 In-Line 6 P/S Pump Kit

### **KIT CONTENTS:**

**P/S Pump, P/S Pulley, P/S Pump Bracket, Hardware**

**Your Ford Saginaw P/S pump upgrade comes with the pump attached to the pump bracket and the pulley already properly installed. Please leave these items assembled for installation.**

### **Installation:**

Attach the bracket to the driver's side of the motor into the two holes that straddle the forward freeze plug with the included bolts.

**NOTE:** This pump kit will not be sealed and leak free until it is adjusted and tightened into final position. The force of the bracket against the reservoir is required to properly seal.



Borgeson Universal Co., Inc.  
9 Krieger Dr. Travelers Rest, SC 29690  
[www.borgeson.com](http://www.borgeson.com)