

BORGESON

Steering You Forward

800337 Small Block Mopar Pump Kit

Installation:

- 1) Remove the two lower timing cover bolts and attach the power steering pump and bracket to the driver's side of the engine block with the 1-1/4" spacers and 2-3/4" bolts provided as shown in the picture below. Please note that these bolts are into the water jacket of the engine and coolant will escape when removing and installing the bolts.



Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com

4/11/18