

BORGESON

Steering You Forward

800338 Big Block Mopar Pump Kit

Installation:

- 1) Bolt the pre-assembled pump kit to the water pump housing as shown below. The upper bolt attaches with the longer 4-1/4" bolt, .29" spacer and Ny-lock nut. The lower bolt is the shorter 3-3/4" bolt with .29" spacer and threads directly into the water pump.



Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com

4/11/18