

BORGESON

Steering You Forward

800339 '64-'69 Small Block Mopar Pump Kit

Installation:

- 1) This pre-assembled Borgeson pump kit attaches to the cast iron water pump housing on the 1964-1969 Mopar LA series small block engines. Remove one water pump bolt next to the mounting boss on the water pump housing. Attach pump kit to the mounting boss with the 2-1/2" bolt, nut and washers provided. Insert the removed water pump bolt through the adjusting slot in the bracket and thread into water pump housing.
- 2) Use the square cut-out on the bracket with a ratchet or breaker bar to adjust belt tension. Tighten water pump bolt to secure tensioned pump in place.
- 3) Fill pump with a quality power steering fluid and bleed system as needed.



Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com