

BORGESON

Steering You Forward

#800340 Lincoln 317 Y-Block P/S Pump Kit

KIT CONTENTS:

P/S Pump, P/S Pulley, P/S Pump Bracket, Hardware

Your Lincoln Y-block Saginaw P/S pump upgrade comes with the pump attached to the pump bracket and the pulley already properly installed. Please leave these items assembled for installation.

Installation:

Attach the bracket to the driver's side cylinder head with the two .120" spacers between the bracket and head and fasten with the two 3/8"-16 X 1-1/8" bolts and washers.



Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com

6/4/26JG