

BORGESON

Steering You Forward

#802407 BBC/LWP P/S Pump Bracket



****Note:** Bracket is intended for use with Saginaw self-contained power steering pumps with two mounting locations on the back or the reservoir. Contains bolts for both metric and SAE threaded pumps.

- 1) If equipped, remove the two mounting studs from the back of the P/S pump.
- 1) Attach the P/S bracket to the back of the pump with the proper two bolts and flat washers for your pump. (Metric or SAE depending on the pump you are using).
- 3) Install pump and bracket to the engine block with the two included 1/2" spacers and two 7/16" X 1-1/2" bolts and lock washers.

Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com