

# **BORGESON**

***Steering You Forward***

## #802414 Big Block Mopar P/S Pump Bracket

### Installation notes:

- 1) Attach your power steering pump to the bracket with either 3 of the 3/8 or M10 bolts with washers depending on the power steering pump you are using. Mount the bracket to the front of the pump with the shorter bolt on top and the two longer bolts with the two .35" spacers on the bottom.

### Installation:

- 1) Bolt the pre-assembled pump and bracket to the water pump housing as shown below. The upper bolt attaches with the longer 4-1/4" bolt, .29" spacer and Ny-lock nut. The lower bolt is the shorter 3-3/4" bolt with .29" spacer and threads directly into the water pump.



Borgeson Universal Company, Inc.  
9 Krieger Dr. Travelers Rest, SC 29690  
(860) 482-8283 www.borgeson.com