

# **BORGESON**

***Steering You Forward***

## #802415 Lincoln 317 Y-Block P/S Pump Bracket

### **Installation:**

- 1) Attach the bracket to the face of the power steering pump using the two .35" spacers and either three 3/8"-16 bolts with washers or three M10 bolts with washers depending on if you are using a metric or SAE pump. The bracket will be much easier to attach if installed prior to the pulley.
- 2) Attach the assembled pump and bracket to the driver's side cylinder head with the two .120" spacers between the bracket and cylinder head and fasten with two 3/8"-16 bolts and washers.



Borgeson Universal Company, Inc.  
9 Krieger Dr. Travelers Rest, SC 29690  
(860) 482-8283 [www.borgeson.com](http://www.borgeson.com)

06/04/2026JG