



Drag Link Adapter General Instructions

Borgeson Drag Link Adapters:

- Borgeson drag link adapters are used to replace the control valve on older Ford and GM vehicles equipped with a linkage assisted power steering.
- The drag link adapter can be used to remove the control valve effectively converting to manual steering or for installation of a modern Borgeson power steering conversion box.
- Disconnect hoses from control valve and slave cylinder and allow fluid to drain.
- Remove and discard slave cylinder and control valve.
- Slide included tie rod clamp over drag link adapter and then thread drag link adapter on to the factory power steering drag link as far as it will go, then back off until the male stud is aligned properly to connect to the pitman arm.
- Position tie rod clamp so it will not interfere with any other components when the steering is turned from full right to full left and then tighten the clamp bolt to secure the drag link adapter in position.