



03/06 TJ Wrangler Mirror Relocation Brackets Installation Instructions Part Number RT30014

Kit Contents:

- Mirror Relocation Brackets (Qty: 2)
- Lock Washers (Qty: 6)
- Countersunk Machine Screws (Qty: 4)
- Flat Washers (Qty: 6)
- Hex Head Machine Screws (Qty: 6)
- Nuts (Qty: 6)

Instructions:

1. Ensure that all components in kit are accounted for.
2. Remove the mirrors from the doors using a T27 Torx bit.
3. Remove the two side bolts from the lower windshield hinge using a T40 Torx bit.
4. Attach the Mirror Relocation Bracket to the windshield hinge using the Countersunk Machine Screws. Tighten using a 3/16" hex key. The Mirror Relocation Bracket should be oriented forward once installed. (See Image)
5. Align the holes in the mirror with the holes in the Mirror Relocation Bracket. Insert the Hex Head Machine Screws through each hole and secure using a Flat Washer, Lock Washer, and a Nut in that order. Tighten the Nut using an 11mm wrench. Repeat for the other side.



While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.



03/06 TJ Wrangler Mirror Relocation Brackets Installation Instructions Part Number RT30014

Kit Contents:

- Mirror Relocation Brackets (Qty: 2)
- Lock Washers (Qty: 6)
- Countersunk Machine Screws (Qty: 4)
- Flat Washers (Qty: 6)
- Hex Head Machine Screws (Qty: 6)
- Nuts (Qty: 6)

Instructions:

1. Ensure that all components in kit are accounted for.
2. Remove the mirrors from the doors using a T27 Torx bit.
3. Remove the two side bolts from the lower windshield hinge using a T40 Torx bit.
4. Attach the Mirror Relocation Bracket to the windshield hinge using the Countersunk Machine Screws. Tighten using a 3/16" hex key. The Mirror Relocation Bracket should be oriented forward once installed. (See Image)
5. Align the holes in the mirror with the holes in the Mirror Relocation Bracket. Insert the Hex Head Machine Screws through each hole and secure using a Flat Washer, Lock Washer, and a Nut in that order. Tighten the Nut using an 11mm wrench. Repeat for the other side.



While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.