13018

MERCEDES BENZ : 1998-2002 ML320, 2003-2005 ML350
1999-2001 ML430, 2002-2005 ML500

10/21/2020

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3,500 LBS. TRAILER WEIGHT & 350 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-877-287-8634

ITEM	QTY	PART NUMBER	DESCRIPTION
\multicolumn{4}{c}{Parts List}			
1	4	10-10546	HHCS,M14X1.5,50,CL10.9,YZ
2	4	30-00194	WASHER,LOCK,9/16,YZ
3	1	CM-13018-SP	.375" SPACER PLATE

FRAME

EXISTING WELD NUT

HITCH WEIGHT: 12 LBS.

INSTALL TIME

   PROFESSIONAL: 30 MINUTES

   NOVICE (DIY): 60 MINUTES

INSTALL NOTES:

   - NO DRILLING REQUIRED

INSTALLATION STEPS

1) Temporarily remove plastic bumper fascia. Carefully remove large center door and both smaller left and right doors. This exposes fascia mounting screws, remove screws and fascia. Note: If vehicle is equipped with outboard spare tire carrier, temporarily remove tire and mounting brackets as necessary.

2) Position hitch over existing weldnuts in bumper beam. Note: If vehicle is equipped with a spare tire bracket mounted on bumper beam, install spacer plate between hitch and bumper. Install fasteners as shown.

3) Torque all hardware to 136 lb.-ft.

**PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS
ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**