



FITTING INSTALL INSTRUCTIONS

Please read these instructions completely before starting the installation.

TOOLS NEEDED

Torque Wrench

O-Ring fittings

1. Lubricate the o-ring with either oil or ATF before installing into the port.
2. Proceed to tighten fitting down to 20 ft-lbs.



NPT fittings

1. Wrap the fitting with 2-3 turns of thread sealing tape or if using liquid, apply a decent amount to lower portion of threads.
2. Install fitting into port and tighten down to 20 ft-lbs.

