



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: 51405
1967-1969 Camaro/Firebird package tray / speaker deck insulation kit

KIT CONTENTS:
Pre-Cut D-Mat insulation Panel
Boom mat damping material
- 1 - 6" x 12"
- 2 - 2" x 12"
• Instructions

TOOLS NEEDED:
Scissors

SAFETY:
Safety glasses
Gloves

NOTE OF CAUTION: Wear eye and hand protection when installing all materials.

OVERVIEW: This kit controls heat and sound on the package tray of 67-69 Camaros and Firebirds

STEP 1. Remove upper back seat cushion and package tray cover.

STEP 2. Clean the package tray area from all grease, dirt and other materials.

STEP 3. The area must be clean for the Boom mat to adhere.

STEP 4. See **Fig 1** for placement of the Boom mat damping material. (Placement marked in red)

5. Peel back and firmly press into place. It must have full contact with the metal to function properly.



Fig 1



Fig 2

STEP 6. Using the Spray adhesive in the kit, spray both the fiber side and the package tray area.

Fig 2

STEP 7 Let dry then lay the precut D-Mat panel on top of the package tray. Some minor trimming maybe needs as variances in models and years may happen.

Fig 3

STEP 8. Reinstall you package tray and seat cushion.



Fig 3