



INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

DESCRIPTION: 2007-UP 170" WB

Floor Kit

KIT CONTENTS:

3D-Mat 30mm Wall Insulation

TOOLS NEEDED:

Cleaner & Degreaser

Rags/Towels

Tools for interior panel removal

SAFETY:

Safety glasses

Gloves

NOTE OF CAUTION: Wear eye and hand protection when installing all materials. Use cleaners or degreasers in a well ventilated area

FLOOR

PLACEMENT OF INSULATION

FRONT OF VEHICLE

REAR OF VEHICLE

