

COOL TAPE

Installation Instructions

NOTE: A clean, dry surface is important for proper adhesion

STEP 1. Clean area with degreaser or isopropyl alcohol and let dry thoroughly.

STEP 2. Cut tape into strips required to cover the area you want to cover.

STEP 3. Peel back a corner of the release liner backing and start to apply the material. Press down the Cool Tape as you pull the backing off of the tape.

NOTE: When applying Cool Tape to an ABS plastic material, an adhesion promoter may be needed (3M Adhesion Promoter Swab) to ensure a long lasting bond.