



HEAT SHROUD INSTALLATION

Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering, Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT.

STEP 1: Measure the length of wires/hoses you need to cover with Heat Shroud

STEP 2: Using sharp scissors or utility knife, cut to the length needed

STEP 3: Wrap Heat Shroud around wires/hoses and close the hook and loop to install.

NOTE: If using near a high heat source, install hook and loop side of Heat Shroud facing away from the heat source.

NOTE: DO NOT INSTALL DIRECTLY ON EXHAUST SYSTEM COMPONENTS