



PERFORMANCE PRODUCTS

Step 1. Disconnect vehicle battery before starting.

Step 2. Remove hardware and old bolts from license plate.

Step 3. Feed the Lite' N Bolt wires through existing plate holes. On back feed the Lite' N Bolt wires through the center of the nylon nut and carefully tighten. Make sure wiring harness or 12V source can be accessed prior to mounting plate to ensue connections.

Step 4. Polarity of wires are specified (diagram). Connect the wires of the Lite' N Boltz to the original wiring. White wires are positive (12V) and black wire is designated for grounding.

Step 5. Seal any exposed wires with electrical tape and reconnect battery

