



INNOVATIVE
**HEAT & SOUND
CONTROL**
SOLUTIONS

RFI Sleeve Installation Instructions

STEP 1. Locate the wires that you wish to cover, you can either pre-measure the length of sleeve needed or install the sleeve and trim off the excess once installed. Use standard household scissors to cut the sleeve.

STEP 2. The Sleeve needs to be grounded using the included ground strap.
You can attach the ground strap in a few different ways.

- A.** Wrap the ground strap around wires you are going to install the sleeve over and simply install the sleeve over the wires, making sure you have good contact with the ground strap.
- B.** Using the supplied crimp connector, you can attach the ground strap at any point to the sleeve. Using pliers, crimp the ground strap to the sleeve, making sure you have secure connection.
- C.** The sleeve is made from Tinned Copper and solders very easily. Using a soldering gun, tin the sleeve and ground strap and then solder the two together.

STEP 3. Open the sleeve and work the wires into the sleeve. Do this for the entire length of the wires to be covered.

STEP 4. Use supplied Quick Fix Tape to wrap each end of the sleeve.

STEP 5. Attach the ringed end of the ground strap to a good clean ground.

Tech Tip Make sure your engine, frame and body are all grounded.