



INNOVATIVE
**HEAT & SOUND
CONTROL**
SOLUTIONS

RFI Wrap Installation Instructions

STEP 1. Locate the wires that you wish to cover, trim the excess wrap off after you have completed wrapping the wires.

STEP 2. The Wrap needs to be grounded using the included ground strap. You can attach the ground strap in a few different ways.

A. Wrap the ground strap around wires you are going to install the Wrap over and simply install the Wrap over the wires, making sure you have good contact with the ground strap.

B. Using the supplied crimp connector, you can attach the ground strap at any point to the wrap. Using pliers, crimp the ground strap to the wrap, making sure you have secure connection.

C. The Mesh Wrap is made from Tinned Copper and solders very easily. Using a soldering gun, tin the wrap and ground strap and then solder the two together.

STEP 3. Start at one end of the wires to be wrapped and start to wrap the wires, overlap the starting point so that the wrap will stay in place. Continue to wrap the wires, making sure to have 100% coverage as you wrap. Trim off any excess wrap.

STEP 4. Use the supplied silicone tape to wrap each end of the sleeve.

STEP 5. Attach the ringed end of the ground strap to a good clean ground.

Tech Tip. Make sure your engine, frame and body are all grounded.