



INNOVATIVE  
**HEAT & SOUND  
CONTROL**  
SOLUTIONS

## REFLECT-A-COOL INSTALLATION INSTRUCTIONS

NOTE A clean, dry surface is important for proper adhesion

**STEP 1.** Clean area with degreaser or isopropyl alcohol and let dry thoroughly.

**STEP 2.** Cut material into shape required to cover the area you want to cover.

**STEP 3.** Peel back a corner of the release liner backing and start to apply the material. Press down the

**NOTE:** When applying Cool Tape to an ABS plastic material, an adhesion promoter may be needed (3M Adhesion Promoter Swab) to ensure a long lasting bond.

**NOTE DO NOT INSTALL DIRECTLY ON  
EXHAUST SYSTEM COMPONENTS**