

OPEN FIRST!!

Parts list for

Master set # 5.18107

1995-99 Mitsubishi Eclipse AWD & FWD



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2011 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front end control arm bushing set: 5.3118
4 - 2337 lower control arm bushing outer.
2 - 3307 lower control arm bushing center.
2 - 15.10.324.39 lower control arm sleeve.
(.875" O.D. x .500" I.D. x 2.140" LG.)
4 - 8164 upper control arm bushing.
4 - 15.10.332.39 upper control arm sleeve.
(.750" O.D. x 10mm I.D. x 1.600" LG.)
1 - 17256 installation instructions.

Rear end control arm bushing set: 5.3119
2 - 8144 lower trailing arm
2 - 15.10.374.39 lower trailing arm sleeve
(.875" O.D. x 14mm I.D. x 2.790" LG.)
6 - 8165 rear knuckle
6 - 15.10.155.39 rear knuckle sleeve
(.750" O.D. X 12mm I.D. X 1.760" LG.)
4 - 8167 upper control arm
4 - 15.10.332.39 upper control arm sleeve
(.750" O.D. X 10mm I.D. X 1.600" LG.)
1 - 17274 installation instructions

Front shock bushing set: 5.8103
(uppers only)
2 - 8163 upper position shock bushing.
2 - 8162 lower position shock bushing.

Rear shock bushing set: 5.8104
(uppers only)
2 - 8163 upper position shock bushing.
2 - 8162 lower position shock bushing.

Manual transmission shifter bushing set: 5.1102
4 - 1101 upper position shifter bushing.
4 - 1102 lower position shifter bushing.
1 - 17271 installation instructions.

Grease:
Formula 5 Prelube.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Additional parts available for your vehicle:

Front anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
16mm	5.5133
18mm	5.5132
19mm	5.5130

Rear anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
12mm	5.5145
15mm	5.5146
18mm	5.5147

Motor mount insert set: 5.1103
manual trans only
(3 Torque mount positions only)

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17225

16/APR/11 MAM