OPEN FIRST!!

SUSPENSIX

Parts list for Master set # 7-18105 1990-96 NISSAN 300 ZX

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

C) 2003 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

Note: It is recommended that this set be professionally installed if you are unfamiliar with this type of work, and a factory service manual be purchased prior to performing any work on your vehicle for proper disassembly, reassembly and torque specs. These instructions are intended for bushing removal and install of Energy Suspension polyurethane bushings, once you have removed the factory component from your vehicle.

Parts list:

Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list **before you** start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front radius/tension rod bushing set: 7.7105

(I.D. of tension rod is 2.513". Use round stock with O.D. 2.500" to press out O.E. Bushing.)

- 2 7119 inner bushing.
- 4 7120 outer bushing.
- 2 15.10.325.39 sleeve(1.000" x .563" x 2.745").
- 4 9.11108 grease.
- 17432 installation instructions.

Front control arm bushing set: 7.3108

(Must reuse existing outer metal shells).

- 2 3311 bushings (front).
- 2 15.10.329.39 (7/8"O.D. x 9/16"I.D. x 2.50" sleeve).
- 2 3312 bushings with built on thrust washer (rear).
- 2 9.11108 grease.
- 1 17423 installation instructions.

Rack and pinion bushing set: 7.10104

- 1 10034 bushing (Drivers side).
- 1 10035 bushing (Passenger side).

Rear sub frame bushing set: 7.4102

Must reuse existing outer metal shell.

- 2 4179 bushing (Frt. position top). 4 4180 bushing (Frt. & RR. position bottom). 2 4181 bushing (RR. Position top). 2 15.10.403.39 (1 1/4"O.D. x .843"I.D. x 3.0" sleeve). 2 15.10.404.39 (1 1/4"O.D. X .843"I.D.x 3.1" sleeve).
- 1 17303 installation instructions.

Updated 9/DEC/04 BRH

Parts list continued:

Front sway bar bushing set: 7.5120

- 2 5528 26.5mm sway bar bushings. (fits factory bracket).
- 9.11108 grease.
- 1 17039 installation instructions.

Rear sway bar bushing set: 7.5119

- 2 5529 26mm sway bar bushings. (fits factory bracket).
- 4 8147 end link grommets, male.
- 4 8148 end link grommets, female. (One grommet per eye).
- 9.11108 grease.
- 17039 installation instructions.

Rear differential carrier bushing set: 7.1108

- 2 4178 bushing (rear).
 - (Must reuse OEM inner cup).
- 2 2401 bushing (front).
- 2 3114 bushing (thrust washer, front).
- 2 15.10.86.39 (3/4"O.D.x1/2"I.D.x 1.70" Sleeve).
- 1 17295 installation instructions.

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.