OPEN FIRST!

Installation Instructions

Front Control Arm Bushing Set 2015+ Ford Mustang / Mustang GT



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2015 Energy Suspension. All rights reserved.

May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle. Wheel alignment is almost always disturbed when suspension components are removed or replaced. It is recommended that you have the alignment checked on your vehicle at a qualified alignment shop. Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list. Prior to installation, make sure that your vehicle is in top mechanical condition and that there are no suspension or steering related problems. This part has been designed to work only with a vehicle that is in good state of repair. No matter how carefully we design our parts, this is one area we have no control over and cannot be held responsible.


Parts List:


4 EA - 03P03575 Outer Bushing

2 EA - 03P03574 Inner Bushing

2 EA - 15P1068639 Inner sleeve (1.25" x .640" x 3.450")

2 EA - 15P0206539 Outer shell (2.837" x 2.250" x 2.300")











Apply grease to the I.D. & O.D. of 03P03474 & 03P03575 and all metal parts that will contact the new polyurethane bushings. Press in the new bushings and sleeve into the shell in the order shown above. Install the control arm back into the vehicle and torque all fasteners to factory specs.