

# INSTRUCTION SHEET FOR SET #7.5122

Read this instruction sheet thoroughly before initiating any work!

*It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's Polyurethane.*

Remove endlink nuts on both sides of car. Remove endlink assemblies. Remove sway bar bracket, remove OEM bushing. Clean and grease bar surface and install Energy Suspension bushing. Repeat for other side. Now assemble endlink assembly as per below picture. Tighten all bolts/nut to factory specifications.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2003 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

**PARTS LIST:** 090403N  
2 - 5748 Sway bar bushings  
2 - 8148 Endlink bushings  
6 - 8147 Endlink bushings  
**\*MUST REUSE OEM STUD, WASHERS, AND NUTS.**

# INSTRUCTION SHEET FOR SET #7.5122

Read this instruction sheet thoroughly before initiating any work!

*It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's Polyurethane.*

Remove endlink nuts on both sides of car. Remove endlink assemblies. Remove sway bar bracket, remove OEM bushing. Clean and grease bar surface and install Energy Suspension bushing. Repeat for other side. Now assemble endlink assembly as per below picture. Tighten all bolts/nut to factory specifications.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2003 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

**PARTS LIST:** 090403N  
2 - 5748 Sway bar bushings  
2 - 8148 Endlink bushings  
6 - 8147 Endlink bushings  
**\*MUST REUSE OEM STUD, WASHERS, AND NUTS.**

# INSTRUCTION SHEET FOR SET #7.5122

Read this instruction sheet thoroughly before initiating any work!

*It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's Polyurethane.*

Remove endlink nuts on both sides of car. Remove endlink assemblies. Remove sway bar bracket, remove OEM bushing. Clean and grease bar surface and install Energy Suspension bushing. Repeat for other side. Now assemble endlink assembly as per below picture. Tighten all bolts/nut to factory specifications.



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2003 Energy Suspension. All rights reserved. May not be reproduced, in any form, or by any means, without the written consent of Energy Suspension.

**PARTS LIST:** 090403N  
2 - 5748 Sway bar bushings  
2 - 8148 Endlink bushings  
6 - 8147 Endlink bushings  
**\*MUST REUSE OEM STUD, WASHERS, AND NUTS.**