

AIR PROPORTIONING SHOCKS

REMOVE THE EXISTING SHOCK FROM THE VEHICLE AND INSTALL THE AIR PROPORTIONING SHOCKS. CUT THE 1/4" AIR LINE GOING TO THE AIR SPRING. INSTALL THE 1/4"x1/4"x5/32" TEE FITTING. ROUTE A LENGTH OF 5/32" AIR LINE FROM THE TEE FITTING TO THE FITTING ON THE SHOCK.

