



**1/4" TBI RISER PLATE
PART # 2457
FITS 1986-95 CHEVY/GMC
TRUCKS**

INSTALLATION INSTRUCTIONS

**IMPORTANT! READ ALL INSTRUCTIONS
BEFORE YOU BEGIN INSTALLATION.**

1. Remove air cleaner and spacer ring.
2. Remove wiring connectors from injectors.
3. Remove fuel lines, and both fuel nut fittings from rear of TBI unit.
4. Remove the 3 screws from the injector housing. Torx size T-20.
5. Remove the injector housing and gasket from main body. No gaskets are necessary you may throw away the old gasket.
6. Install injector spacer, injector housing and bolt it back down to main body using the 3 Allen screws supplied.
7. Reinstall fuel nut fittings and lines in rear of TBI unit.
DO NOT OVER TORQUE.
8. Reinstall spacer ring and air cleaner.



For best results use with a Trans-Dapt TBI Spacer.

12438 Putnam Street • Whittier, CA 90602
tel (562) 921-0404 • fax (562) 921-7515
website: www.hedman.com
email: techsupport@hedman.com

2457-Instructionsheet.cdr