

CARE AND USE INSTRUCTIONS - PN:53251

Thank you for selecting an X-act Contour[™] Second Seat Floor Liner from Husky Liners Inc. Your new floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats* before installing your new floor liners. However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.

