



# X-ACT CONTOUR

## FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:53311

---

Thank you for selecting Xact Contour™ Front Floor Liners from Husky Liners Inc. Your new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER

RIGHT OR PASSENGER

NOTE THAT PART #53311 WILL WORK IN APPLICATIONS WITH THE SINGLE MAT RETAINING HOOK OR DUAL MAT RETAINING POSTS. TO INSTALL DRIVER'S SIDE LINER SIMPLY POSITION LINER OVER EXISTING RETAINER AND PRESS DOWN TO SEAT LINER OVER THE RETAINER.

