



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN: 55341

Thank you for selecting X-act Contour™ Front Floor Liners from Husky Liners Inc. Your **new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, do not remove the factory-installed carpeting.***

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER



RIGHT OR PASSENGER

TO INSTALL YOUR LINERS, POSITION THEM IN THE FLOOR PANS AS SHOWN ABOVE. THE **DRIVER'S** SIDE LINER ATTACHES TO THE FACOTRY FLOOR MAT RETENTION POSTS. JUST ALIGN THE LINER OVER THE POSTS AND PUSH DOWN ON THE LINER TO SNAP IT INTO PLACE.