



X-ACT CONTOUR® FLOOR LINERS

PT #78361

CARE AND USE INSTRUCTIONS

Thank you for selecting an X-act Contour® Floor Liner from Husky Liners. Your new second seat liner is custom molded to fit your specific vehicle. The liner is made to take the place of your factory floor mat(s). **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR X-ACT CONTOUR CUSTOM MOLDED SECOND SEAT FLOOR LINER



TO INSTALL YOUR SECOND SEAT LINER, FIRST MOVE YOUR FRONT ROW SEATS COMPLETELY FORWARD. THEN, INSTALL YOUR NEW LINER, POSITIONING IT IN THE VEHICLE AS SHOWN ABOVE. LASTLY, REPOSITION YOUR FRONT ROW SEATS AS DESIRED.



X-ACT CONTOUR® FLOOR LINERS

PT #78361

SOME VEHICLES AND TRIM PACKAGES WILL HAVE FRONT BENCH SEATS, FRONT CENTER CONSOLE OR REAR BENCH SEATS.
TRIM 1 IS PROVIDED ONLY IF YOUR VEHICLE HAS A CENTER CONSOLE.
TRIM 2 IS PROVIDED ONLY IF YOUR VEHICLE HAS A REAR BENCH SEAT.

