



# WEATHERBEATER™ FLOOR LINERS

PT #14501

## CARE AND USE INSTRUCTIONS

---

Thank you for selecting a WeatherBeater® Floor Liner from Husky Liners. Your new 2<sup>nd</sup> seat liner is custom molded to fit your vehicle. The liner is made to take the place of your factory floor mat(s). **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

## INSTALLATION INSTRUCTIONS FOR YOUR WEATHERBEATER 2<sup>ND</sup> SEAT FLOOR LINER



TO INSTALL YOUR 2<sup>ND</sup> SEAT LINER, FIRST MOVE YOUR FRONT ROW SEATS COMPLETELY FORWARD. THEN, INSTALL YOUR NEW LINER, POSITIONING IT IN THE VEHICLE AS SHOWN ABOVE. IF YOUR VEHICLE HAS A FRONT ROW CONSOLE BETWEEN THE BUCKET SEATING, YOU WILL NEED TO TRIM YOUR LINER AS SHOWN ABOVE. TO TRIM, USE A UTILITY KNIFE OR HEAVY SHEARS AND, USING THE MOLDED IN TRIM GUIDE, REMOVE THE SECTION OF THE CENTER HUMP COVERAGE THAT MATCHES UP TO THE FRONT ROW CONSOLE. LASTLY, REPOSITION YOUR SECOND ROW SEATS AS DESIRED.