



# X-ACT CONTOUR

## FLOOR LINERS

### CARE AND USE INSTRUCTIONS – PN:52781

Thank you for selecting X-act Contour™ Front Floor Liners from Husky Liners. Your new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER

RIGHT OR PASSENGER

Your driver's side liner is designed to attach to the factory floor mat retainers. The two retention clips in the liner will set over the top of the "twist-lock" fasteners. Once the liners are in position over the fasteners, turn the twist-lock 90° to lock the liner in place.