



## X-ACT CONTOUR® FLOOR LINERS

PT #53391

### CARE AND USE INSTRUCTIONS

---

Thank you for selecting an X-act Contour® Floor Liner from Husky Liners. Your new second seat liner is custom molded to fit your vehicle. The liner is made to take the place of your factory floor mat(s). **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

### INSTALLATION INSTRUCTIONS FOR YOUR X-ACT CONTOUR SECOND SEAT FLOOR LINER



TO INSTALL YOUR LINER, FIRST MOVE BOTH FRONT SEATS COMPLETELY FORWARD TO ALLOW ACCESS TO THE REAR FLOOR PANS. WITH THIS DONE, INSTALL YOUR LINER POSITIONING IT AS SHOWN ABOVE. ONCE THE LINER IS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED.

IF YOUR VEHICLE HAS THE OPTIONAL FACTORY SUBWOOFER, YOU WILL NEED TO TRIM YOUR LINER TO ACHIEVE THE CORRECT FIT - PLEASE SEE THE TRIM INSTRUCTIONS ON THE BACK OF THIS PAGE.



# X-ACT CONTOUR® FLOOR LINERS

PT #53391

TO TRIM, USE A UTILITY KNIFE OR HEAVY SHEARS AND REMOVE THE RECESSED AREA OF THE LINER AS SHOWN BELOW. THE EDGE FORMED BY THE RECESS WILL BE USED AS YOUR TRIMMING GUIDE.



IMAGE OF OPTIONAL SUBWOOFER





**X-ACT CONTOUR®**  
**FLOOR LINERS**

**PT #53391**