



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS P/N 53591

Thank you for selecting a X-act Contour Floor Liner from Husky Liners Inc. Your new center hump liner is custom molded to fit your Ram Crew & Quad Cab truck. The liner is made to take the place of your factory floor mat. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, *do not remove the factory-installed carpeting.*

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409[®] or Glass Plus[®] work well. Use of Armor All[®], Son-of-a-Gun[®] or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR RAM CREW CAB & QUAD CAB TRUCK CENTER HUMP LINER

