



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN: 54671

Thank you for selecting X-act Contour™ Floor Liners from Husky Liners. Your new third seat floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



TO EASE INSTALLATION OF YOUR NEW THIRD SEAT LINER, FOLD/TUMBLE/SLIDE THE 2ND ROW SEATS COMPLETELY FORWARD TO ALLOW FULL ACCESS TO THE THIRD SEAT FLOOR PAN. NEXT, POSITION THE LINER AS SHOWN ABOVE. ONCE THE LINER IS IN PLACE, MOVE THE FRONT SEATS BACK TO THE DESIRED POSITION.

IF YOUR VEHICLE HAS A 2ND ROW BENCH SEAT OR 2ND ROW CONSOLE, A TRIM IS REQUIRED TO ACHIEVE THE PROPER FIT. SEE THE BACK OF THIS PAGE FOR DETAILS.

TO TRIM FOR A 2ND ROW BENCH OR 2ND ROW CONSOLE, USE THE MOLDED IN TRIM GROOVE TO REMOVE THE TONGUE SECTION OF THE LINER AS SHOWN BELOW. A UTILITY KNIFE OR HEAVY SHEARS WORK WELL FOR TRIMMING

