

## HONDA RIDGELINE FRONT MUD GUARD INSTALLATION INSTRUCTIONS

*Please read instructions thoroughly before installation.*

### Tools Required

- Short Phillips screwdriver

### Package Contents

- Driver & passenger side mud guard
- #10 SEM screw (qty. 4)
- U-clip (qty. 4)
- Instruction sheet

**NOTE:** It may be necessary to remove the wheels depending on the tools being used for installation.

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fasteners from locations C and D. Do not discard.
3. Remove existing plastic fasteners from locations A and B. Discard.
4. Pull fender liner back and install a U-clip on each sheet metal tab in locations A and B.
5. Place fender liner back into its original location.
6. Attach mud guard to rear fender with existing fasteners at locations C and D. Do not tighten.
7. Install a #10 SEM screw at locations A and B threading into the U-clip on the sheet metal tab.
8. Ensure the mud guard is parallel with the ground before tightening.

