

**EXPLORER****REAR MUD GUARD INSTALLATION INSTRUCTIONS**

*Please read instructions thoroughly before installation.*

**Tools Required**

- 9/32 Socket

**Package Contents**

- Rear Mud Guard
- Instruction Sheet

**Determine which mudguard you have by locating the part number molded in the mounting flange (5950 DS and 5950 PS).**

1. Clean and degrease the mud guard location area on the fender before installation. Remove existing fasteners from locations A, B, C and D.
2. Attach mud guard to rear fender with factory fastener at locations A, B, C and D, check fit and make sure mud guard is parallel to ground before tightening. Install clip where shown.

