

**HONDA RIDGELINE REAR MUD GUARD
INSTALLATION INSTRUCTIONS**

Please read instructions thoroughly before installation.

Tools Required

- Short Phillips screwdriver

Package Contents

- Driver & passenger side mud guard
- #10 SEM screw (qty. 2)
- U-clip (qty. 2)
- Instruction sheet

NOTE: It may be necessary to remove the wheels depending on the tools being used for installation.

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fasteners from locations A and B. Do not discard.
3. Attach mud guard to rear fender with existing fasteners at locations A and B. Do not tighten.
4. Install a #10 SEM screw at location C going through the mud guard and fender liner. Use the U-clip as a nut behind the fender liner.
5. Ensure the mud guard is parallel with the ground before tightening.

