

IAG I-Line TPE Armrest Cover for 2021+ Ford Bronco



IAG-ACC-F3062 IAG I-Line TPE Armrest Cover for 2021+ Ford Bronco

Part# IAG-ACC-F3062

Congratulations on the purchase of your IAG I-Line TPE Armrest Cover, and thank you for choosing IAG Off-Road. These instructions are intended for users with basic mechanical skills. Professional installation is not required. The average installation time is approximately 2-5 minutes.

Video instructions can be found at the link below.

<https://youtu.be/ISGOgXg1cFg>

Step 1/8



IAG-ACC-F3062 IAG I-Line TPE Armrest Cover for 2021+ Ford Bronco

Part# IAG-ACC-F3062

Tools Required For Installation:

None

Step 2/8

Step 3/8

Numbered annotations (1)

 TPE Armrest



Step 4/8

Numbered annotations (1)

- 1 Open the armrest



Step 5/8

Numbered annotations (1)

- 1 Wrap the armrest cover around each side of the factory armrest Note the cut away is towards the front of the armrest





Step 6/8

Numbered annotations (1)

- 1 With the cut notch towards the front securely fit on to the bottom corners



Step 7/8

Numbered annotations (1)

- 1 Move to the other side and wrap the armrest around all corners

Step 8/8

Numbered annotations (1)

- 1 Enjoy your new armrest

