



## **Throttle Body Spacer Installation Instructions**

Jeep 3.8L

Part #62153

- 1. Remove the air intake tube from the throttle body and air box.**
- 2. Remove the 4 bolts that mount the throttle body to the intake.**
- 3. Install the JET Power-Flo spacer placing the gasket between the throttle body and the spacer with the supplied longer bolts and washers.**
- 4. Reinstall the Air Intake assembly.**

JET Performance Products – 17491 Apex Circle – Huntington Beach, CA 92647

Phone 714-848-5515 Fax 714-847-6290

