



JET Power-Flo
Throttle Body Spacer Installation Instructions
4.2L Envoy and Trailblazer
2.8, 2.9, 3.5 & 3.7L Canyon/Colorado
3.5 & 3.7L Hummer H3
Part #62134

1. Remove the air intake assembly and intake box from throttle body.
2. Remove the 4 nuts and studs that mount the throttle body to the intake manifold
3. Install the JET Power-Flo throttle body spacer using the new o-ring.
4. Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.
5. Install the 2 new extender plates using the allen head screws to the mounting holes for the air intake assembly. (NOTE: These are used only for 4.2L Envoy/Trailblazer applications)
6. Verify the throttle linkage, cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.
7. Reinstall the Air Intake assembly.

JET Performance Products
17491 Apex Cir.
Huntington Beach, Ca 92647
714-848-5515 Fax: 714-847-6290