

JET Power-Flo
Throttle Body Spacer Installation Instructions
Nissan 3.3L Frontier/Pathfinder/Xterra
Part #62147

- 1. Remove Air Intake Assembly from throttle body.**
- 2. Remove the 4 bolts that mount the throttle body to the intake manifold**
- 3. Remove the gasket and clean any residue from the surfaces. Be careful not to get any gasket material in the intake manifold.**
- 4. Remove the bolts that mount the throttle linkage bracket and retain for latter use.**
- 5. Install the JET Power-Flo throttle body spacer using one gasket between the intake manifold and the spacer and one gasket between the throttle body and the spacer.**
- 6. Replace the 4 bolts that mount the throttle body to the intake manifold using the new bolts and flat washers supplied in the kit.**
- 7. Install the new linkage extender plates using the allen head screws. Reinstall and reconnect the linkage assembly and reconnect the cables to the throttle body.**
- 8. Verify the throttle linkage ,cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.**
- 9. Reinstall the Air Intake assembly.**