

***JET Power-Flo***  
**Throttle Body Spacer Installation Instructions**  
**2005-2006 Toyota Tundra**  
**Part #62148**

1. **Remove Air Intake Assembly from throttle body.**
2. **Remove the hose clamp that holds the air intake to the throttle body.**
3. **Remove the nuts and studs that mount the throttle body to the intake manifold.**
4. **Install the JET Power-Flo throttle body spacer using the supplied gasket between the JET spacer and throttle body.**
5. **Replace the 4 bolts that mounted the throttle body using the new bolts and flat washers supplied in the kit.**
7. **Reinstall the air intake to the throttle body.**
8. **Reinstall and reconnect the vacuum lines and hoses that you removed on the air intake system.**